



HIS-ML23.8-Fxxx Models

Front View




Side View




HIS-ML23.8-Fxxx Models

Rear View




Bottom View




HIS-ML23.8-Fxxx Models

Bottom View (showing Cable Connections)




Mounting Diagram




HIS-ML23.8-Sxxx Models

Front View




Side View




HIS-ML23.8-Sxxx Models

Rear View




Bottom View




HIS-ML23.8-Sxxx Models


Bottom View (showing Cable Connections)



Mounting Diagram




Cutout Dimensions (All Models)



VB-22A Accessory Mounting Bracket

Rear View



Bottom View

