

Installation Instructions

VB-17F

Accessory Mounting Bracket for HIS-ML17 Monitors

- Lay the monitor face down on the edge of a bench.
 Place a soft cloth or foam between the monitor and bench to prevent scratches.
- Remove and set aside the twelve nuts from the locations marked "A" in Figure 1. Temporarily remove the collar from the rear cover of the monitor.
- 3. Remove and set aside the three screws from the locations marked "B" in Figure 1.

NOTE: If the chassis is moved while these three screws are removed, the monitor will become misaligned. Be careful not to move the chassis while screws are removed.

- 4. Remove and discard the two screws from the locations marked "C" in Figure 1.
- 5. Place the Accessory Bracket onto the rear of the monitor as shown in Figure 1.
- 6. Reinstall the three screws that were removed in step 3 in the locations marked "B" in Figure 1.
- 7. Install the provided two screws and lockwashers in the locations marked "C" in Figure 1.
- Unless you will be installing the monitor into a panel immediately, reinstall the collar using the twelve nuts that were removed in step 2 in the locations marked "A" in Figure 1.

FIGURE 1 - REAR VIEW OF ML17 MONITOR (FACE DOWN)




FIGURE 2 - BOTTOM VIEW

